







Installation Instructions

Product: Extreme Plus Front w/ Heidts spindle Instruction Part Number: 6000291


Vehicle


Make: GM


Model: Chevrolet / BelAir

Year(s): 55-57

ATTENTION: Read this before going any farther!
Returns will not be accepted for ANY installed PART or
ASSEMBLY. Use great care to prevent cosmetic damage
when performing wheel fit check.







Notices - Read and Follow BEFORE ATTEMPTING INSTALLATION


- All installations require proper safety procedures and protective eyewear.
- All installations assume basic mechanical skill and a factory service manual for the vehicle on which the installation is to be performed.
- All references to LEFT side of vehicle always refer to the Driver's side of the vehicle.
- Any installation requiring you to remove a wheel or gain access under the vehicle requires use of
 jack stands appropriate to the weight of the vehicle. In all cases Baer recommends jack stands
 rated for at least 2-tons.
- A selection of hand tools sufficient to engage in the installation of these products is assumed and
 is the responsibility of the installer to have in his/her possession prior to beginning this
 installation. All installations, which require removal of hydraulic hoses and/or bleeding of the
 brakes, require appropriate fitting/line wrenches, as well as a safety catch can and protective
 eyewear. Other than these items, if unique or special tools are required they are listed in the
 section for that step.
- ALWAYS CONFIRM WHEEL FIT PRIOR TO BEGINNING INSTALLATION OF ANY BRAKE SYSTEM OR "UPSIZED" ROTOR UPGRADE! In addition to already having checked fit using the Baer Brake Fit Templates available online at www.baer.com, always place the actual corner assembly or a combination of the caliper assembly fit onto the rotor into the actual wheel to reconfirm proper clearance is available between the caliper and the wheel before proceeding with the actual installation. Returns will not be accepted for systems that have been partially or completely installed. Use extreme car when performing wheel fit check to prevent cosmetic damage.

Baer, Incorporated 3108 W. Thomas Road, Suite 1201 Phoenix, Arizona 85017 Ph. (602) 233-1411 Fax. (602) 352-8445 Email. Brakes@baer.com www.baer.com



When installing rotors on any Baer Products be sure to follow the direction of rotation indicated on





the rotor hat area with either an arrow, or an "L" for left, or an "R" for right, or both. "L" or left, always indicates the driver's side of US spec vehicles.

Images shown are "L" left rotors.

- A proper professional wheel alignment is required for any system requiring replacement of the front spindles, or tie rod ends. Follow factory prescribed procedures and specifications unless otherwise indicated.
- At all times stop the installation if anything is unclear, or the parts require force to install. Consult directly with Baer Technical Staff in such instances to confirm details. Please have these instructions, as well as the part number machined on the component that is proving difficult to install, as well as the make, model, and year (date of vehicle production is preferred) of your vehicle available when you call. Baer's Tech Staff is available from 8:30-am to 5-pm Mountain Standard Time (Arizona does not observe Daylight Savings Time) at 602 233-1411 Monday through Friday.

Disconnect the fluid hose at the frame and cap with the supplied vinyl caps. Using pliers or channel locks, remove the hose lock and slip the hose end out of the frame bracket. See photos on the next page.



Line wrench on hardline

Vinyl cap

Remove the brake drum from the spindle. Unbolt and remove the brake backing plate. The shoes and other components can be left in place.

Thoroughly clean the spindle pin and mounting surfaces to allow the new Baer components to seat properly.

The caliper placement is intended to be behind the spindle pin centerline. On some applications this may interfere with the steering arm. If this is the case with your system the caliper must be mounted ahead of the centerline. For this reason, the crossover tubes and bleeder screws have been left out of the calipers. Refer to the caliper orientation sheet on the following page and photos below.



Desired installation for left (drivers side) intermediate and caliper mount bracket.

Bolt the intermediate bracket to the spindle using the supplied 7/16" x 1.25" bolts and torque to 65 ft-lbs.

Install the caliper mount bracket with the supplied 14mm x 45mm bolts. Just snug these as caliper centering will be necessary.


Install the correct spacers on the radial mount studs for your rotor diameter: 13.5" .325" spacer

14" .575" spacer

15" .825" spacer

Install your steering arm (if removed) and place the caliper on the studs to check for adequate clearance.

If adequate clearance is available, continue with installation. If the steering arm hits the caliper, move these brackets to the front side of the spindle.



Right side with caliper leading, and trailing (preferred) shown. Note piston sizes, smallest contacts rotor first.

When you have determined the proper caliper orientation for your application, the crossover tubes can be installed in the lower openings and the bleeder screws in the upper openings. Use the diagram above to determine locations. Torque the crossover tubes to 20 ft-lbs using a line wrench. Bleeders can be just snug until ready for bleeding.

Remove the caliper to continue installation or bracket relocation.

Install the new Baer billet aluminum hub. The new Timken bearings are pre-packed with Red Line synthetic grease. Do not add more grease. Apply a small amount of grease to the hub seal surface on the spindle pin and install the hub. Tighten the nut to 5-10 ft-lbs and spin the hub to seat the bearings. Loosen and re-tighten the nut while spinning the hub several times. Loosen the nut, tighten to remove all play, tighten approximately 1/16th turn to give a small amount of pre-load. Install cotter pin and dust cap.

Install the correct side rotor and secure with 2 lug nuts using washers to prevent scarring the rotor hat.

With pads removed, install correct caliper (bleeder screw points up), washers and retaining nuts (black 12 point 12mm-1.25). Snug these bolts for measuring caliper alignment.



Measure from rotor to caliper body


Measure the gap from the rotor to caliper body at 4 points, top inside and outside, bottom inside and outside. Write down all measurements. Subtract the top inside measurement from top outside. This will require a shim at the top bracket bolt equal to half of this difference to center the caliper. For instance, inside measurement of .065", outside of .105" has a difference of .040 which would require a .020" shim installed to center. Do the same with the bottom measurements to center this also. Getting these gaps as close as possible, within .005", will keep the possibility of excessive noise to a minimum. This may require different thickness shims top and bottom.

Select the required shims from the kit provided. Remove the caliper. Loosen the bolts from the intermediate bracket. Install the appropriate shims, removing one bolt at a time, and snug the same bolts for fit check.

Reinstall the caliper and recheck gap measurements. Re-shim if necessary. When proper shimming has been achieved, remove caliper. Take the bolts from the intermediate bracket one at a time keeping the shims in place and replace with the 14mm x 45mm bolts. Torque to 110 ft-lbs. Reinstall the caliper and torque the 12 point nuts to 75 ft-lbs.

If you do not have access to a dial caliper, these measurements can be made with pads installed using a feeler gauge between the rotor and pad. Take measurements from top inside and outside, then bottom inside and outside. Minimum clearance is .010" between pad and rotor, but gaps as close to equal as possible at all four locations is best.

Install the steel braid hose with one copper washer on each side of the banjo fitting. Finger tighten the banjo bolt. Connect the hose to the hardline and install the hose lock. Position the hose to avoid interference with the wheel and suspension components through the entire range of motion. Tighten fitting and banjo bolt to 15-20 ft-lbs.



Copper washer placement

Repeat these steps for the other side and recheck all attachment points and fittings.

Refer to Bleeding and Rotor Seasoning procedures contained on a separate sheet, or on www.baer.com

For service components and replacement parts contact your Baer Brake Systems Tech Representative